


Kodiak Viewer iPhone App Instructions (v2.0)




Download the "Kodiak Viewer" app from the App store and open the app.




Navigate to the "Scan" screen.




Click on "Kodiak" to add the camera to your "Cameras" screen, then navigate to the "Cameras" screen.




Click on your "Kodiak Camera"




Press the "Toggle Camera" button to turn the Wi-Fi on.




Keep the app open, but navigate to your phone's Wi-Fi screen. Wait for "Kodiak" to appear (may take up to 30 seconds), then connect to it. **Password 12345678**




Once connected to the Wi-Fi, go back to the "Kodiak Viewer" app and press the "Sync" button. * Your phone will automatically connect to the network if it has been paired previously and no other known networks are present.



Wait approximately 20-30 seconds for the thumbnails to appear. Then click on the ones you'd like to download or delete and press the respective button. Swipe to the right to load more pictures.



Press the "Live" button to switch the camera to Live mode. This allows you to change settings and format the card remotely. * Simply click on SD Card Capacity and Battery Power at any time to display them.



Click on a setting option to change the setting. The app will indicate if the change was a success or not. If the setting fails, simply try clicking on it again and it should indicate success. Click on the format button to confirm and format (erase) the card. Switch back to USB mode to Sync photos again.



Click on the gallery tab to view downloaded photos. Click on a thumbnail to view it in full screen and optionally send it to your device's camera roll for sharing.